


Adjusting Bowkaddy to Fit Parallel-Limb Bows



Pic 1 – One pin falls into outside bottom hole on main support arm; the other pin falls outside main support arm. The friction of the rubber washer between the 2 pieces stabilizes Bowkaddy during bow insertion, after which the bow itself will provide stability.



Pic 2 – Bowkaddy set for Mathews parallel limbs



Pic 3 – 2006 Mathews Switchback XT in Bowkaddy